

Flight Plans

Creating a Flight Plan (Point-n-Shoot method)

The G-1000 can store up to 99 numbered flight plans. Additionally each of the stored Flight Plans can be used in reverse and each one can contain up to 31 waypoints. Unlike Direct to mode, the Flight Plan Mode requires you to enter an identifier for the starting point. Three methods of creating Flight Plans are the **Spelling**, **Point-n-Shoot** and the **Most Recent List** method.

- 1 PRESS **FPL**. Opens the Active Flight Plan window (FPL1).
- 2 ROTATE Small FMS Knob on click clockwise to display the Flight Plan Catalog (FPL2).
- 3 PRESS **NEW** ▲ soft key.
- 4 PUSH IN the joystick to turn the map cursor (flashing arrow) on. (Over the airport/waypoint)
- 5 PUSH the **LD WPT** ▲ soft key on the bottom of the screen to enter the waypoint selected as the first waypoint.
- 6 PUSH IN and MOVE the joystick in the direction of the next waypoint.

NOTE: This is called panning. Even though the next waypoint may not be visible initially, as the pointer is moved, the map will scroll so the pointer remains visible.

NOTE: The map scale may still be changed to view more or less by ROTATING the joystick.

- 7 When the identifier for the waypoint is highlighted, PRESS the **LD WPT** ▲ soft key on the bottom of the screen to enter the waypoint into the flight plan.
- 8 Repeat steps #6 and #7 above to enter remaining waypoints.
- 9 When finished PRESS **MENU** to open the Page Menu window.
- 10 If necessary, ROTATE Large FMS Knob to highlight “Store Flight Plan” option.
- 11 PRESS **ENT** twice. The flight plan is stored as the next available number.
- 12 PRESS **FPL** to deactivate the cursor and return to the original page.